



Curb Inlet Filter (Pigs-in-a-Blanket") Sd2-P

- Install filter after asphalt pavement installation.
- Wrap 8" concrete blocks in filter fabric and span across catch basin inlet.
- Face openings in blocks outward.
- Leave a gap of approximately 4 inches between the curb and the filters to allow for overflow to prevent hazardous ponding.
- Install outlet protection below storm drain outlets.



Engineered Fabric Specialists

2450 PLEASANTDALE ROAD
ATLANTA, GA 30340
PH: (770)409-1515 FAX: (770)409-1117

Curb Inlet Filter (Pigs-in-a-Blanket")

PROPOSED INSTALLATION OF
Pigs-n-a-Blanket
AT CURB DRAIN INLETS

DATE: January 7, 2008

1

1